



## LanTEKII & III Series Software Upgrade Instructions

1)



LT2\_3xxx.ZIP



unzip



LT2\_3xxx.IDL

2)



LT2\_3xxx.IDL



copy



USB Stick

3)



4)



~ 2 min

Upgrade

